

SLIPCOAT APPLICATION INSTRUCTIONS

SlipCoat lubricant is designed to reduce friction between the treadbelt and deck. It is required for all institutional treadmills. Proper and timely application of **SlipCoat** will prevent premature failures due to excessive wear and load. Items affected by inadequate lubrication are the treadbelt, deck, motor, and motor controller.

When to Lubricate:

Landice L-Series institutional treadmills should be lubricated on a monthly basis. Lubrication is not required for home usage, but if desired, should not be done more than once per year unless otherwise instructed by a Landice factory representative. Only use SlipCoat by Landice. Most standard greases, waxes, and silicon sprays will build up on the rollers and affect belt slippage and tracking.

How to Lubricate:

Lift up the edge of the treadbelt and squeeze one full packet of SlipCoat underneath the center of the treadbelt.

Walk about 10 steps on the treadmill at a speed of 1.0 mph. This will moisten approximately an 8" track underneath the center of the entire treadbelt.

Turn off the treadbelt and allow it to dry for approximately 10 minutes.

NOTE: Do not use SlipCoat on any other area of the Treadmill.

Note: Do not get Slipcote on TOP of Treadbelt. This will make the treadbelt very slippery and makes the treadmill dangerous to use. We recommend using rubbing alcohol applied to a sponge to remove any SlipCoat on the treadbelt.

Apply Landice SlipCoat between the belt and deck.

